

性能試験規格項目	L MAX. (uH)		L MIN. (uH)		Qo			L (uH)			MHz fo	uH L	MIN Qo	
	1	2	1	2	1	2	3	1	2	3				
3.5 MHz	14.25 7k	14.38 14.39	14.59 14.40	5.63 5.35	5.61 5.37	66 62	65 55	63 56	10.5 :	10.5	3	10.5	10.5	50 40
7 MHz	6.65 7k	6.70 7.35	6.65 7.24	2.68 2.62	2.72 2.64	71 54	71 55	70 56	5.0 :	5.0	:	5.0	5.0	60 40
14 MHz	2.71 7k	2.71 2.75	2.72 2.72	1.10 1.021	1.10 1.023	73 56	71 55	72 54	2.0 :	2.0	:	2.0	2.0	60 40
28 MHz	2.76 7k	2.75 3.19	2.77 3.20	1.132 1.081	1.120 1.185	60 50	61 51	61 53	1.75 :	1.75	:	1.75	1.75	50 40
21 MHz	2.30 7k	2.29 2.36	2.30 2.39	0.94 0.880	0.95 0.891	64 56	65 54	66 56	1.6 :	1.6	:	1.6	1.6	40 50
50 MHz	0.841 7k	0.840 1.02	0.825 1.01	0.601 0.641	0.599 0.632	80 66	80 67	80 67	0.75 :	0.75	:	0.75	0.75	70 50
80 MHz	0.306 7k	0.306 0.301	0.306 0.300	0.231 0.209	0.248 0.209	60 67	60 65	61 66	0.26 :	0.26	:	0.26	0.26	50 50
144 MHz	0.1182 7k	0.1180 0.1235	0.1181 0.1226	0.135 0.1015	0.135 0.1012	54 54	52 55	55 56	0.11 :	0.11	:	0.11	0.11	40 :

200P
120P
70P
25P
40P
15P
10P
10P

巻数	4~6	3~2	2~1	3~1
80 MHz	1T	3T	2T	5T
7k	1T	3T	2T	5T

巻数	6~4	8~2	2~1	3~1
28 MHz	10k	6T	6T	2T
7k	7k	7T	7T	1T

巻数	6~4	3~2	2~1	3~1
3.5 MHz	3T	14T	14T	2T
7k	3T	15T	15T	1T

巻数	3~2	3~2	3~2
44 MHz	10k	2T	2T
7k	3~1	2 1/2 T	2 1/2 T

巻数	6~4	1~2	2~3	3~1
2 MHz	10k	6T	5T	2T
7k	2T	6T	6T	1T

巻数	6~4	1~2	2~3	3~1
7 MHz	3T	9T	10T	2T
7k	3T	10T	11T	1T

巻数	4~6	3~2	2~1	3~1
14 MHz	10k	1T	5T	2T
7k	7k	2T	4T	1T

巻数	6~4	3~2	2~1	3~1
50 MHz	10k	5T	4T	2T
7k	2T	6T	4T	1T

巻数	6~4	1~2	2~3	3~1
14 MHz	2T	5T	7T	2T
7k	3T	6T	7T	1T

株式会社 千代田
秋葉原店 東京都千代田区外神田1-8-6
〒101-0021 電話 (03) 3253-4411 (代)
FAX (03) 3253-4108